How to apply the Bednorz-Seal

1 Pull the seal through the openings that are to be secured.



2 Bend the top of the strap downwards and position the pin in the oval slot.



Fold the seal at the point where it is marked "> <".</p>
Press both parts of the seal head together, until there is an audible "click".



4 The seal should only be removed by authorised personnel using appropriate tools, e.g. tin snips.



At least 5mm of unmarked strap head should be visible between the seal head and the embossed section of the strap. The end of the strap should also be clearly visible from the side of the sealhead and should move freely within the oval slot.





+49 (0) 6107 - 60 33

info@bednorz.com

+49 (0) 6107 - 62 49 7

Fon:

Fax:

Mail: